

Replacement Sheet

67/143



FIG. 86

NEW			
NAME OF TYPE STYLE			
<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>	Helvetica-Light Helvetica-Bold Helvetica-Oblique Helvetica-BoldOblique Helvetica-Condensed-Black Helvetica-Condensed-Bold Helvetica-Condensed HelveticaNeue-Black HelveticaNeue-Bold		
NAME OF TYPE STYLE HelveticaNeue-Bold			
BASE ANGLE	<input type="text" value="0"/>	DEGREE	CHARACTER HEIGHT CIRCUMSCRIBED HEIGHT <input type="text" value="50"/> mm <input type="text" value="1.968504"/> mm BOX HEIGHT <input type="text" value="280.112"/> CLASS <input type="text" value="198.50456"/> pt
VERTICAL ANGLE	<input type="text" value="100"/>	%	
HORIZONTAL SCALE	<input type="text" value="100"/>	%	
OBLIQUE ANGLE	<input type="text" value="0"/>	DEGREE	
CHARACTER SPACING	<input type="text" value="2"/>	%	
LINE SPACING	<input type="text" value="0"/>	mm	
ENTIRE LENGTH	<input type="text" value="0"/>	mm	<input type="text" value="0"/> mm
ARRANGEMENT FORM <input type="radio"/> TOP LEFT <input type="radio"/> TOP <input type="radio"/> TOP RIGHT <input type="radio"/> CENTER LEFT <input type="radio"/> CENTER <input type="radio"/> CENTER RIGHT <input checked="" type="radio"/> BOTTOM LEFT <input type="radio"/> BOTTOM <input type="radio"/> BOTTOM RIGHT		SET FORM <input checked="" type="radio"/> LANDSCAPE <input type="radio"/> PORTRAIT	
HEIGHT PRIORITY <input checked="" type="radio"/> ON <input type="radio"/> OFF		REVERSED VIDEO CHARACTER <input type="radio"/> BLACK <input checked="" type="radio"/> WHITE	
ARRANGEMENT POSITION <input type="radio"/> IN <input checked="" type="radio"/> OUT		AUTO KERNING <input type="radio"/> OFF <input checked="" type="radio"/> ON	
DELETE		CALL	NEW DOCUMENT ↵